



Model 1088A/B Firmware Upgrade Instructions

Introduction

These instructions cover the installation of replacement program ROMs (firmware) in the Model 1088A/B series GPS clocks. ROM upgrades allow you to set up automated Daylight Saving Time (DST) time changes for any geographical region, including recent DST changes in North America. Please read through the entire set of instructions prior to attempting this work.

NOTE: After installing the new program ROM, you must restore the clock to factory default settings for it to function correctly. Instructions to restore to factory default settings are included.

Required Equipment

1. Torx T-25 or slot screw driver
2. IC Removal Tool (or small blade screwdriver)

Saving Original Configuration Information

Each clock has a set of operating parameters that are configured into memory. It is advantageous to record these configuration settings prior to disassembly.

1. For 1088A/B series clocks, press the SETUP key and sequentially scroll through the various menus to write down your current settings.
2. Use the ENTER key with any menu to sequence through individual settings and confirm them.

Disassembly

1. First turn the power switch to OFF and disconnect the power cord. For clocks with Options 07 or 08 power supply options, instead of IEC-320 power receptacles, be careful with open voltages.
2. Using a T-25 driver (or flat-blade screwdriver), remove the four M-25 screws securing the cover and lift off the cover.

Installing the Program ROM

1. The program ROM is located at U4 (see Figure 1).
2. Use the IC removal tool or small blade screwdriver to remove the old program ROM.
3. Install the new ROM. Observe the correct IC orientation and make sure the IC pins line up well on both sides of the socket. If necessary, use a pin-bending tool to line up the pins.
4. If you have Option 28 installed in your clock, go to the special instructions included called, "Option 28 – Time, Frequency, Phase Monitor Firmware Upgrade Instructions." You will install the Option 28 ROM at this time. Otherwise, go on to Reassembly and Startup.



Reassembly and Startup

1. Replace the clock cover and tighten the four M-25 screws that secure it to the clock chassis.
2. Connect the power cord and turn the power switch ON (if equipped with a power switch).

Configure Clock and Settings

1. Connect a null-modem cable between a computer and the main serial port on the clock.
2. Open a terminal program (e.g. HyperTerminal) with port settings of 9600, 8, N, 1.
3. Reset the clock to factory defaults by either of two methods:
 - For Models 1088A/B, typing in the following command in the terminal window (The command is sent to the clock after typing the last character):
1088XX
 - Alternatively, at startup you can press the SETUP key until you get the message SET FACTORY DEFAULTS? and press ENTER. Follow the on-screen messages to complete the reset. It should take a few seconds.
4. Type in the serial command listed below according to your clock model. This command sets your clock to the correct version.

Model	Serial command
1088A	0,1088xz
1088B	1,1088xz

5. Press the SETUP key to set up your installed options (see Saving Original Configuration Information).
6. If you have Option 28 installed in your clock, go back to Step 3 on the Option 28 Firmware Upgrade Instructions.
7. Cycle power to check model message on display.
8. After the clock finishes the normal startup and locks, reconfigure the clock to your previously configured settings (see Saving Original Configuration Information).
9. Place clock back into service.




Figure 1. Model 1088B Main Board
Showing Program ROM Location



How to Configure DST from the Front Panel

Automatic Settings include setting the Starting and Stopping Day of week, Minute after midnight, Month and Week of the Month.

1. Press the SETUP button twice to reach the display that reads "SET LOCAL HOUR?" Press ENTER and the display should read (first line) "SET LOCAL OFFSET" (second line) "HOUR:MIN 00:00" Press the UP or DOWN button to adjust the clock to your local offset from UTC. Press ENTER to set. The offset in California is -8:00.
2. The display should now read (first line) "SET DST/SUMMER TIME?" (second line) OFF. The possible modes are OFF, ON and AUTO. To configure the clock to make automatic changes at the correct times each year, you will need to press the UP button and change the mode to "AUTO" and press ENTER.
3. START DAY: The display should read (first line) "DST/SUMMER START" (second line) "DAY: SUN". Values are from SUN through SAT. First use the UP or DOWN buttons to set up the starting day for DST/Summer Time and press ENTER.
4. START MINUTE: The display should read (first line) "DST/SUMMER START" (second line) "MIN: 0000". Values are from 0000 to 1440 (minutes in a day). Press either the UP or DOWN button to adjust the starting time number of minutes after midnight and press ENTER.
5. START MONTH: The display should read (first line) "DST/SUMMER START" (second line) "MONTH: JAN". Values are JAN through DEC. Press either the UP or DOWN buttons to adjust the starting month for DST/SUMMER TIME and press ENTER.
6. START WEEK OF MONTH: The display should read (first line) "DST/SUMMER START" (second line) "First SUN of JAN". Values are First, Second, Third, Last, 2nd from Last and 3rd from Last. Press either the UP or DOWN button to adjust the starting week of the month and press ENTER.
7. STOP DAY: The display should read (first line) "DST/SUMMER STOP" (second line) "DAY: SUN". Values are from SUN through SAT. First use the UP or DOWN buttons to set up the ending day for DST/Summer Time and press ENTER.
8. STOP MINUTE: The display should read (first line) "DST/SUMMER STOP" (second line) "MIN: 0000". Values are from 0000 to 1440 (minutes in a day). Press either the UP or DOWN button to adjust the ending time number of minutes after midnight and press ENTER.
9. STOP MONTH: The display should read (first line) "DST/SUMMER STOP" (second line) "MONTH: JAN". Values are JAN through DEC. Press either the UP or DOWN buttons to adjust the ending month for DST/SUMMER TIME and press ENTER.
10. STOP WEEK OF MONTH: The display should read (first line) "DST/SUMMER STOP" (second line) "First SUN of JAN". Values are First, Second, Third, Last, 2nd from Last and 3rd from Last. Press either the UP or DOWN button to adjust the ending week of the month and press ENTER.

How to Configure DST From the Serial Port

There are several RS-232 port commands that will set up the DST/Summer Time information and return the current setup.

1. MODE SETUP: Use the command 1,mDT to set up which mode you want to operate: OFF, ON or AUTO, with m=mode (0 through 2), 0 = OFF, 1 = ON and 2 = AUTO. To set up the DST/Summer Time to AUTO type in the command 1,2DT.
2. RETURN CURRENT SETTINGS: Use the command 0DT to return the current DST/Summer Time settings.



3. **START TIME and DATE:** You can set up the Starting Time and Date with one string, 2,w,x,y,zDT; “2” signifies the Start Time command.
4. **STOP TIME and DATE:** You can set up the Stopping Time and Date with one string, 3,w,x,y,zDT; “3” signifies the Start Time command.

where:

w = Month, with 0=JAN, 1=FEB through 11=DEC.

x = WeekOfMonth, with 0=First, 1=Second, 2=Third, 3=Last, 4=2nd from Last, 5=3rd from Last

y = DayOfWeek, with 0=SUN, 1=MON through 6=SAT.

z = Minutes, settings from 0 through 1440, starting at midnight.

Start Time Example:

2,2,1,0,120DT means that Daylight Saving begins at 2:00 am on the second Sunday of March. “120” means the number of minutes after midnight.

STOP TIME AND DATE: You can set up the Stop Time and Date with one string, 3,w,x,y,zDT; “3” signifies the Stop (or ending) Time command.

where:

w = Month, with 0=JAN, 1=FEB through 11=DEC.

x = WeekOfMonth, with 0=First, 1=Second, 2=Third, 3=Last, 4=2nd from Last, 5=3rd from Last

y = DayOfWeek, with 0=SUN, 1=MON through 6=SAT.

z = Minutes, settings from 0 through 1440, starting at midnight.

Stop Time Example:

3,10,0,0,120DT means that Daylight Saving begins at 2:00 am on the first Sunday of November. “120” means the number of minutes after midnight.





PLEASE SEND US A LIST OF UPDATED CLOCKS BY MODEL AND SERIAL NUMBER

FAX BACK NUMBER: (805) 238-5717

List of serial numbers by Model Number. If necessary, copy this form for additional entries.

Model Number	Serial Number	Serial Number	Serial Number	Serial Number

PLEASE RETURN ALL ROMS TO ARBITER SYSTEMS:

ARBITER CONTACT INFORMATION

Arbiter Systems, Inc.
1324 Vendels Circle, Suite 121
Paso Robles, CA 93446
U.S.A.
(805) 237-3831
(800) 321-3831
(805) 238-5717 FAX
email: techsupport@arbiter.com